



Cr-48 Chromebook Battery Replacement

Replace the battery.


Written By: Robert McLaughlin



INTRODUCTION

Use this guide to replace the battery in your CR-48.

Step 1 — Remove the Battery



- Slide the switch on the bottom of the laptop until the battery pops out.
- Once the battery pops out, you can remove it.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 04:01:12 PM.